



**SAFETY FIRST:** If you are collecting the equipment for someone else

please make sure this sheet is given to the equipment user to read. In accordance with Health and Safety in Employment Act requirements, this sheet should be given to the site supervisor if the equipment is being hired for use at a commercial worksite so that the information is available to all users.

### Required Safety Equipment



Goggles



Hard Hat



Visual Inspection

### Pre Start Checks and Safety

- ! Always ensure gib board is sitting correctly on cradle
- ! Maximum sheet size is 1.22m x 4.88m
- ! Maximum lifting weight is 68kg
- ! Ensure brakes are on when required
- ! Always tilt frame before loading gib board sheets
- ! Once loaded and raised the panel can be rotated 360°
- ! Always slide out extension frames for larger sheets
- ! Unit can be wheeled around to position sheets before lifting
- ! Always ensure hard hat is worn at all times
- ! Never apply excessive pressure on unit to jack item up, the unit is designed to lift the sheet into position but the final stage is to be done as the sheet is screwed
- ! Always lower unit slowly to prevent it coming down too fast and injuring someone or allow chain and/or wire ropes to tangle
- ! Only lift one sheet at a time

### When Operating

- Tilt frame before loading gib sheets
- Lift gib sheets onto frame
- Tilt frame to level and ensure it locks into this position
- Rotate handle/wheel and position sheet to where it is required.
- Never apply excessive pressure on unit to jack item up, the unit is designed to lift the sheet into position but the final stage is to be done by hand as the sheet is screwed.
- Continue to screw sheet in position

### Setting Up procedure

- Wind up manual winch type:
- Position wheel assembly on flat ground
- Lift main section and insert into wheel assembly
- Lift frame section and position on top of main section
- Slide out frame extensions and lock in place
- Release locking pins and lower leg assemblies and lock in place
- Reposition wind up wheel
- Lift frame section and position on top of main section
- Slide out frame extensions and lock in place

### Raising and lowering

- To raise turn wheel until you reach your desired height
- To lower turn wheel in opposite direction to lower to base height

### Stopping and After Use

- Dismantle unit in reverse order to setting up